


- DE** Montageanleitung
FR Instructions de montage
EN assembly instructions
IT Istruzioni per Installazione
ES Instrucciones de montaje
NL Handleiding
DK Monteringsvejledning
PT Manual de Instalação
PL Instrukcja montażu
CS Montážní návod
SK Montážny návod
ZH 组装说明
RU Инструкция по монтажу
HU Szerelési útmutató
FI Asennusohje
SV Monteringsanvisning
LT Montavimo instrukcijos
HR Uputstva za instalaciju
TR Montaj kılavuzu
RO Instrucțiuni de montare
EL Οδηγία συναρμολόγησης
SL Navodila za montažo
ET Paigaldusjuhend
LV Montāžas instrukcija
SR Uputstvo za montažu
NO Montasjeveiledning
BG Инструкция за употреба
SQ Udhëzime rreth montimit
AR تعليمات التجميع



Raindance Select S 120

26530000


26530400



Raindance Select S 150

28587000


28587400



Raindance Select S 120

26530000



26530400




Raindance Select S 150

28587000

28587400




97708000



Raindance Select S 120
26530000 / 26530400




2










Raindance Select S 150
28587000 / 28587400





	P-IX	DVGW	SVGW	ACS	WRAS	NF	KIWA
26530XXX	P-IX 28216/IB		X	X	X		X
28587XXX	P-IX 6989/IB		X	X	X		X





hansgrohe

Hansgrohe · Auestraße 5 · 9 · D-77761 Schiltach
Telefon +49 (0) 78 36/51-1282 · Telefax +49 (0) 7836/511440
E-Mail: info@hansgrohe.com · Internet: www.hansgrohe.com

3/2017
9.01654.04